



Installation instructions for special equipment

Headrests for rear seats

91.6

Model 201


Procedure

- 1 Remove rear seat and rear seat backrest (91-170).
- 2 Mark holes for eyes (1) on covering of rear seat backrest using the eyes as a template.




Different dimensions on vehicles up to and as of 09/89 model enhancement.

Dimensions up to 09/89 model enhancement



- 3 Punch marked holes into covering by means of a hollow punch.
- 4 Insert eyes into covering. Then mount washers from the rear.


Dimensions as of 09/89 model enhancement.



- 5 Disengage insulating mat (a) and fold in downward direction.




- 6 Insert guide rails and rivet-on.



- 2 Guide rail
3 Rivet

- 7 Re-engage insulating mat.

- 8 Install rear seat and rear seat backrest (91-170).



- 2 Guide rail
a Insulating mat

9 Insert headrests into rear seat backrest



Parts ordering note

Parts required for installation are shown in the following replacement parts data:

Designation		Parts fiche group or SA
Headrests and scope of delivery Vehicles up to 09/89	With leather	56 578
	With MB-Tex	56 489
	With fabric	56 504
	With velours	56 509
Headrests and scope of delivery Vehicles as of 09/89	With leather	56 765
	With MB-Tex	56 758
	With fabric	56 751
	With velours	56 770
	With luxury equipment	56 967
	With leather sports seat	56 788
	With fabric sports seat	56 784

Available from: Plant 06 (ZVL-Germersheim)